



Ph: 954-763-6581
Fx: 954-765-1425
www.bestrentalservice.com

OPERATING INSTRUCTIONS
BIG JOHN GAS GRILL (5'4" X 16.25")

ALL GAS COOKING EQUIPMENT MUST BE USED OUTSIDE

1. Make sure all burner valves are off. Connect the regulator to the propane tank. Open the fuel tank valve.
2. Safety check all connections with a leak detector or soap and water for leaks. Do not use grill if any leaks are detected. Gas burns and so do leaks. Safety is up to you.
3. Light a long fireplace match. Put through the grate and ONLY THEN turning on the gas valve and ignite the burner tube. The second burner will be ignited by the first. This must be done for each section.
4. If unit does not light, wait five (5) minutes for gas to disperse and repeat above instructions.
5. Operate burners on high until lava rock becomes hot. Then turn the burners down to a lower setting and allow the radiant heat of the rock to provide the heat for cooking.
6. Cooking is the same as any gas-fired barbecue. Any sauces should be applied toward the end of cooking to eliminate flare-ups.
7. If a malfunction is discovered at any time, the use of the grill must be discontinued immediately.
8. To turn off grill; Close tank valve on the propane tank. Close all white levers and disconnect the regulator from the tank. The regulator always stays connected to the hose. A replacement charge will be incurred for grills that are missing the regulator.
8. The grill must be returned clean for the deposit to be refunded.

By my signature on these instructions, I acknowledge that I have read and understand same, and have received a copy of them.

Signature

Print Name

Thank you for choosing Best Rental Service