



Ph: 954-763-6581  
Fx: 954-765-1425  
www.bestrentalservice.com

## OPERATING INSTRUCTIONS CRESCOR SMALL HEATING CABINET "I"

### WARNINGS:

Do not operate the unit until you have read and understand the instructions. This machine may cause serious injury and should never be operated by a minor. Machine must be properly grounded to prevent electrical shock. If a malfunction is discovered at any time, the use of this machine must be discontinued immediately. Best Rental Service does not assume any liability for injury due to careless handling and/or reckless operation of this equipment.

NOTE: Temperature gage gives the inside temperature. This cabinet is designed to maintain the temperature of HOT prepared foods. It will not cook them.

NOTE: No. 7 1/2 setting will give you about 140 °F. Proper food holding temperature is 140 ° F

NOTE: Preheat cabinet for 45 minutes. This unit will hold 8 food pans or 9 sheet/bun pans.

### To turn unit on:

1. Plug unit into a grounded 15-amp wall outlet. Place cabinet in a well ventilated area.
2. Push switch to "ON". Yellow light will come on.
3. Turn thermostat to the temperature you need.
- 4, Pre-heat cabinet for 30 minutes.
4. Put food into cabinet.
5. Open the door vent when less humidity is needed.

### To turn unit off.

1. Rotate the thermostat to the "OFF" position.

By my signature on these instructions, I acknowledge that I have read and understand same, and have received a copy of them.

---

Signature

---

Print Name